



Restoration

# DEEP CLEANER

**Biocide for sanitizing surfaces with mould and microbiological growths.**



- High cleaning strength
- Miscible in water
- Wide range of action
- Quick and lasting effect

## APPLICATION AREAS

- Dirty surfaces contaminated by microbiological growth
- Rooms and environments with a great deal of mould
- Pretreatment before applying a Wall Remedy System

## FEATURES

General-use biocide with high cleaning strength that works on a wide range of surfaces having microbiological growth, fungus, moulds and/or for preparing contaminated substrates before the Wall Remedy System is applied.

## WARNINGS

The biocidal active ingredients are irritants so appropriate precautions must be taken when handling this product. When applying the sanitizing solution, wear PVC or PE gloves and safety glasses in order to prevent contact with the skin, eyes and mucous membranes.

- Use a roller or brush to apply the product and do not spray.
- Do not apply onto delicate and sensitive substrates.
- Do not use at temperatures below +5°C.

- Ventilate the rooms during and after application.
- The fungal growth must be manually/mechanically removed from the concerned surface.

### INSTRUCTIONS FOR USE

After the conditions of the substrate have been adequately assessed, apply DEEP CLEANER and thus removing the growth; proceed with any subsequent processing steps after 24-48 hours.

### WAITING TIMES

Allow the product to act for 24-48 hours before proceeding to the subsequent processing steps.

### TECHNICAL SPECIFICATIONS

Consistency	Liquid
Colour	colourless
Colour	1,00 kg/l
pH (at 20 °C)	4,0-5,0 Completely miscible in water
Packaging	bottle
Packaging size	8x750 ml
Pallet	46 cardboards

The information contained in this document is reported on the basis of our experience and knowledge; therefore, any recommendations and suggestions made are without any guarantee and must be verified before using the product by those who intend to use it, who assume all responsibility that may result from its use since the conditions of use are not under our direct control. In case of doubt, it is always advisable to make preliminary tests and/or ask for the intervention of our technicians. Torggler reserves the right to modify, replace and/or delete the items, as well as to change the product data in this document without prior notice; in this case the indications given here may no longer be valid. Always refer to the latest version of the data sheet, available at [www.torggler.com](http://www.torggler.com). Version 23.11.2021.